

DGCA NO	SUBJECT	REFERENCE	COMPLIANCE	APPLICABILITY
DGCA / SOCATA TB-20 / 1	TO ENSURE THE INTEGRITY OF THE TRIM CONTROL SYSTEM	FAA AD 86-17-03	'AS IN AD'	'AS IN AD'
DGCA / SOCATA TB-20 / 2	TO PREVENT POSSIBLE STRUCTURAL DAMAGE AND LOSS OF AIRFRAME INTEGRITY	FAA AD 86-21-08	'AS IN AD'	'AS IN AD'
DGCA / SOCATA TB-20 / 3	TO PREVENT PLAY IN ENDS ASSEMBLY OF STABILATOR CONTROL ROD	FAA AD 87-03-04 B V A D NO.87-003(A) AND SOCATA TBSB.NO 29	'AS IN AD'	'AS IN AD'
DGCA / SOCATA TB-20 / 4	INSPECTION ON AILERON BALANCING WEIGHTS FOR LOOSENESS	BVAD NO.87-031(A) AND SOCATA SB NO.28 FAA AD 87-12-09 REV.1	AS IN AD & SB	AS IN AD & SB
DGCA / SOCATA TB-20 / 5	INSPECTION / MODIFICATION ON MAIN LANDING GEAR BOXES	FAA AD 88-02-05 BVAD NO.87-030(A) AND SOCATA SB NO.30	AS IN AD & SB	AS IN AD & SB
DGCA / SOCATA TB-20 / 6	BRAKE HYDRAULIC PIPE ATTACHMENT	BVAD NO.87-118(A) AND SOCATA SB NO.33	AS IN AD & SB	AS IN AD & SB
DGCA / SOCATA TB-20 / 7	NOSE LANDING GEAR L.H. HYDRAULIC PIPE	BVAD NO.87-117(A) AND SOCATA SB NO.34	AS IN AD & SB	AS IN AD & SB
DGCA / SOCATA TB-20 / 8	REAR ATTACHMENT FRAME OF HORIZONTAL STABILIZER	FAA AD NO.87-22-02 REV.1 BVAD NO.87-1 41(A) REV.2 SOCATA SB NO.35	AS IN AD & SB	AS IN AD & SB
DGCA / SOCATA TB-20 / 9	INSPECTION OF FRONT SEATS SAFETY BELTS	BVAD NO.89-0-97(A) AND SOCATA SB NO.44	AS IN AD & SB	AS IN AD & SB
DGCA / SOCATA TB-20 / 10	INSPECTION OF MAIN AND NOSE LANDING GEARS ARTICULATED STAYS FOR JAMMING	BVAD NO.(REV.2) 89-096(A) AND SOCATA SB NO.40 AND 45/2	AS IN AD & SB	AS IN AD & SB
DGCA / SOCATA TB-20 / 11	INSPECTION AND REPLACEMENT OF NOSE LANDING GEAR LEVER ADJUSTING SCREW	BVAD NO. (REV.1) 89-108(A) AND SOCATA SB NO.46/1	AS IN AD & SB	AS IN AD & SB
DGCA / SOCATA TB-20 / 12	FRAME NR.O-FIREWALL	BVAD NO.(REV.1) 89-175(A) AND SOCATA SB NO.42/1	AS IN AD & SB	AS IN AD & SB
DGCA / SOCATA TB-20 / 13	FUEL TANKS-PREVENT INTRODUCTION OF WATER INTO THE FUEL TANK SYSTEM	BVAD NO.(REV.2) 89-177(A) AND SOCATA SB NO.48/2	AS IN AD & SB	AS IN AD & SB
DGCA / SOCATA TB-20 / 14	FUEL SYSTEM-LOSS OF PRIMING IN THE FUEL SYSTEM ON GROUND	BVAD NO.(REV.1) 89-183(A) AND SOCATA SB NO.47/1	AS IN AD & SB	AS IN AD & SB
DGCA / SOCATA TB-20 / 15	OIL COOLER	BVAD NO.90-1 43(A) AND SOCATA SB NO.50-1	AS IN AD & SB	AS IN AD & SB
DGCA / SOCATA TB-20 / 16	INSPECTION OF THE HORIZONTAL STABILIZER BALANCE WEIGHTS	FAA AD 91-15-10 AND SOCATA AEROSPATIALE IMPERATIVE SB NO.57	AS IN AD	'AS IN AD'
DGCA / SOCATA TB-20 / 17(R1)	DOORS ----- CABIN ACCESS DOOR HOOKS ----- INSPECTION / REPLACEMENT	EASA AD 2007 -0101	'AS IN AD'	'AS IN AD'
DGCA / SOCATA TB-20 / 18	AUTOPILOT CONTROL SYSTEM	BVAD 91-145(A)	'AS IN AD'	'AS IN AD'
DGCA / SOCATA TB-20 / 19	FRAME NO.0-CONSOLE SIDE	BVAD 91-160(A) AND SOCATA TBSB 49	AS IN AD & SB	AS IN AD & SB
DGCA / SOCATA TB-20 / 20	EXHAUST SYSTEM	BVAD 92-152(A)R4	'AS IN AD'	'AS IN AD'
DGCA / SOCATA TB-20 / 21	FUEL TANK AIR VENT SYSTEM	BVAD 92-225(A) R1 & SOCATA TB SB	AS IN AD & SB	AS IN AD & SB

		NO. 10.067.28 R1		
DGCA / SOCATA TB-20 / 22	DETECTION OF GALVANIC CORROSION AND REPLACEMENT OF STIFFENERS, IF REQUIRED RUDDER BALANCE WEIGHT	BVAD NO.93-012(A)R2 AND SACOTA SB 10-071-55 R3	AS IN AD & SB	AS IN AD & SB
DGCA / SOCATA TB-20 / 23	FRONT SEATS	BVAD 94-114(A) R1 AND SOCATA SB 10-075-25 R1	AS IN AD & SB	AS IN AD & SB
DGCA / SOCATA TB-20 / 24	MAIN LANDING GEAR	DGAC AD 94-266(A) R3 SB ID-080-57 R3	'AS IN AD'	'AS IN AD'
DGCA / SOCATA TB-20 / 25	MAIN LANDING GEAR	BVAD 95-084(A) SB NO.10.091.157	AS IN AD & SB	AS IN AD & SB
DGCA / SOCATA TB-20 / 26	LANDING GEAR REARIN FLIGHT MANUAL	BVAD 97-032(A) SB N 10-105-32	AS IN AD & SB	AS IN AD & SB
DGCA / SOCATA TB-20 / 27	FUEL SSYSTEM	DGAC AD 1999-062(A)	'AS IN AD'	'AS IN AD'
DGCA / SOCATA TB-20 / 28	VERIFICATION OF THE PRESENCE OF THE VERTICAL STABILISER FORWARD JUNCTION DOUBLER	BVAD NT 1999-319(A)	'AS IN AD'	'AS IN AD'
DGCA / SOCATA TB-20 / 29	PROPELLER GOVERNOR CONTROL	DGAC AD 1999-386(A)	'AS IN AD'	'AS IN AD'
DGCA / SOCATA TB-20 / 30	TIGHTENING OF NOSE GEAR MOUNT BOTH	DGAC AD 2001-001(A)	'AS IN AD'	'AS IN AD'
DGCA / SOCATA TB-20 / 31	RUDDER BEARING	DGAC AD 2001-002(A)	'AS IN AD'	'AS IN AD'
DGCA / SOCATA TB-20 / 32	SEAT UNLOCKING	DGAC AD 2001-005(A)	'AS IN AD'	'AS IN AD'
DGCA / SOCATA TB-20 / 33	NOSE GEAR FORK	DGAC AD 2001-304(A)	'AS IN AD'	'AS IN AD'
DGCA / SOCATA TB-20 / 34	DOOR HINGE ATTACHMENT ON UPPER FUSELAGE	DGAC AD 2001-307(A)	'AS IN AD'	'AS IN AD'
DGCA / SOCATA TB-20 / 35	WINGS FRONT ATTACHING BOLTS	DGAC AD 2001-306(A)	'AS IN AD'	'AS IN AD'
DGCA / SOCATA TB-20 / 36	AMMETER CIRCUIT MODIFICATION	DGAC AD 2001-446(A) R1	'AS IN AD'	'AS IN AD'
DGCA / SOCATA TB-20 / 37	GIMBAL JOINT - AILERON AND ELEVATOR CONTROL INSPECTION	DGAC AD 2003-368 R2	'AS IN AD'	'AS IN AD'
DGCA / SOCATA TB-20 / 38	NOSE & MAIN LANDING GEAR ACTUATOR	DGAC AD 2002-574(A)	'AS IN AD'	'AS IN AD'
DGCA / SOCATA TB-20 / 39	PITCH TRIM ACTUATOR INSPECTION AND REPAIR (ATA-27)	DGAC AD 2003-286(A)	'AS IN AD'	'AS IN AD'
DGCA / SOCATA TB-20 / 40	MAIN LANDING GEAR HINGED STRUT (ATA 32)	DGAC AD 2003-390(A)	'AS IN AD'	'AS IN AD'
DGCA / SOCATA TB-20 / 41	TO PREVENT UNSAFE CONDITION DUE TO THE INTERFERENCE BETWEEN THE WING SPAR LOWER BOOM AND THE WHEEL	FAA AD 2007-02-04	'AS IN AD'	'AS IN AD'